

Formula for calculating panel widths:
 BI-PARTING
 Gross opening width + 295mm =
 Then divide by the number of panels required.
 The maximum panel width is 900mm.
 SINGLE WING
 Gross opening width + 102.5 =
 Then divide by the number of panels required.
 The maximum panel width is 900mm.

NOTE
 Roller offsets between 150mm and centre pivot are possible.
 Please contact our technical department for advice on panel widths.

