


Panels may be parked practically anywhere providing there is sufficient space and support above the head track.

Roller centres and position of track junctions will vary according to panel widths; panel thickness; and the total number of panels.
Contact our technical department for exact dimensions.



Calculate approximate panel widths as follows:
 (Gross opening width) - 200mm =
 Then divide this net width by the no. of panels required.
 The maximum panel width is 1240mm.